



Icefree Sapphire Ltd - Icefree P.R.V. 3000 Installation

POSITION

Select a suitable position preferably in a wall insuring that the valves will not be influenced by air movement from evaporators and fans etc This position should be accessible from both sides noting that a mains supply will be necessary to energise the valve heater on the outside of the cold store.

INSTALLATION

Drill a 75mm hole through both skins of the wall/ceiling panel to accept the valve body. Insert the valve body from the outside of the cold store after first applying a bead of silicon sealant around the edge of the hole. Fix the outer plate to the panel using the four fixing holes with the 25mm flange head screws provided.

The extension pipe should be cut if necessary to suit the panel thickness and once fitted silicon should be applied around the raw/cut edge of the panel/pipe. The inner louvered cover can then be fitted using the 25mm flange head screws.

The mains supply flex can then be connected to a correctly fused 240 volt supply.

1 x P.R.V 3000 = 30 watts. This should be a continuous supply.

